LED Turn Signal Reminders



LED before and after trimming and sanding



Front masked and the rest of the body painted



Trim ends with diagonal cutters then sand ends flat



Installed

Wiring and Final Install



Mount with 3M side molding tape



Tap into signal wire circuit between this connector and the front turn signal



Drill hole to route wires



In operation